

Microsearch Laboratories Test Results

The UV System was tested in a 95 cubic metre surgery for a period of 4 weeks. For the first 2 weeks the system was left off and the second 2 weeks the UV System was turned on.

95 cubic metres surgery test results

	System Off										System On									
	MON	TUES	WED	THUR	FRI	MON	TUES	WED	THUR	FRI	MON	TUES	WED	THUR	FRI	MON	TUES	WED	THUR	FRI
BACTERIA	3,900	4,100	6,200	4,900	8,400	7,800	3,900	4,700	8,400	2,800	240	190	20	80	70	90	70	40	70	60
YEASTS	700	900	1,600	1,400	700	900	1,300	1,100	2,400	7,000	100	60	80	90	90	40	110	120	40	240
MOULDS	300	780	900	450	600	220	330	430	700	600	80	40	40	40	50	90	40	50	60	30

